



## Instrumentation Amp (INA)




## FeatherBoard / LEDs


Create solder joint on JP2 to narrow the Band Pass frequency range  
Default: Wide input frequency band, use when recording EMG, EOG  
Configured: Narrow input frequency band, use for EEG, EOG, and ECG




## 1000x Gain (Bandpass)



C8 (BPFC\_C) & R3 (BPFC\_R) on the back side of the PCB can be used to configure the bandpass filter. Use them to configure output Gain (decrease) & Band (frequency range).



## Power supply filtering




Bridge all three pads of the solder jumper to configure for 2 Electrode operations instead of the 3 electrodes  
Note: 2 electrodes will give noisier output than 3 electrodes!

## Electrode reference


LOGO1  
LOGO\_UDLABS  
Upside Down Labs LOGO

LOGO2  
LOGO\_Coconut  
BOARD1  
FeaterWing Board


LOGO3  
CoconutResearch



## Amp Ref + Driven Right Leg (DRL)



## Jack Input



## Header pins / Connectors

TL074H based BioAmp Single chip biopotential amplifier 5v compatible EXG hardware Records EMG, ECG, EOG, and EEG <b>Upside Down Labs / dusjagr</b>	
Sheet: /	UPlabs: contact@upside-downlabs.tech
File: BioAmp-EXG-PIIL1206.sch	dusjagr: marc@dusseiller.ch
<b>Title: BioAmp EXG FeatherWing</b>	
Size: A4	Date: 2022-10-01
KiCad E.D.A. eeschema 5.1.10-88a1d61d5890ubuntu20.04.1	Rev: 1.0f
	Id: 1/1